# **Step 1: Ensure/Double Check Permissions on Sensitive Files**

- 1. Permissions on /etc/shadow should allow only root read and write access.
  - Command to inspect permissions: Is -I /etc/shadow
  - Command to set permissions (if needed):
- 2. Permissions on /etc/gshadow should allow only root read and write access.
  - Command to inspect permissions: Is -I /etc/gshadow
  - Command to set permissions (if needed):
- 3. Permissions on /etc/group should allow root read and write access, and allow everyone else read access only.
  - Command to inspect permissions: Is -I /etc/group
  - Command to set permissions (if needed):
- 4. Permissions on /etc/passwd should allow root read and write access, and allow everyone else read access only.
  - Command to inspect permissions: Is -I /etc/passwd
  - Command to set permissions (if needed):

# **Step 2: Create User Accounts**

- 1. Add user accounts for sam, joe, amy, sara, and admin.
  - Command to add each user account (include all five users):

sudo adduser sam

sudo adduser joe

sudo adduser amy

sudo adduser sara

sudo adduser admin

- 2. Ensure that only the admin has general sudo access.
  - Command to add admin to the sudo group: sudo usermod -aG sudo admin

### **Step 3: Create User Group and Collaborative Folder**

- 1. Add an engineers group to the system.
  - Command to add group: sudo addgroup engineers
- 2. Add users sam, joe, amy, and sara to the managed group.
  - Command to add users to engineers group (include all four users):

sudo usermod -ag engineers sam sudo usermod -ag engineers joe

sudo usermod -ag engineers amy


sudo usermod -ag engineers sara

- 3. Create a shared folder for this group at /home/engineers.
  - o Command to create the shared folder: **sudo mkdir /home/engineers**
- 4. Change ownership on the new engineers' shared folder to the engineers group.
  - Command to change ownership of engineer's shared folder to engineer group:
    sudo chown root:engineers engineers

# **Step 4: Lynis Auditing**

- 1. Command to install Lynis: sudo apt-get install lynis
- 2. Command to see documentation and instructions: man lynis
- 3. Command to run an audit: lynis audit system
- 4. Provide a report from the Lynis output on what can be done to harden the system.

Screenshot of report output:



#### **Bonus**

- 1. Command to install chkrootkit: sudo apt-get install chkrootkit
- 2. Command to see documentation and instructions: man chkrootkit

- 3. Command to run expert mode: sudo chkrootkit -x
- 4. Provide a report from the chrootkit output on what can be done to harden the system.
  - Screenshot of end of sample output:

